



SPARE wózki widłowe  
 Al. Jerozolimskie 261, 05-816 Michałowice k/Warszawy  
 tel / fax: 0- 22 723 92 90  
 e-mail : [info@spare.pl](mailto:info@spare.pl)  
[www.spare.pl](http://www.spare.pl)

Opony pneumatyczne **Continental** do wózków widłowych – zalecane ciśnienie pracy.

Rozmiar opony	Liczba PR (przekładek)	Zalecane ciśnienie [bar]
4.00 - 8	6	8.00
	10	10.00
5.00 - 8	10	10.00
16 x 6 - 8 (150/75-8)	16	10.00
18 x 7 - 8 (180/70-8)	16	10.00
6.00 - 9	14	9.00
	16	10.00
21 x 8 - 9 (200/75 - 9)	14	9.00
	16	10.00
6.50 - 10	14	10.00
7.50 - 10	12	8.00
23 x 9 - 10 (225/75-10)	14	7.00
	20	10.00
7.00 - 12	14	9.00
	16	10.00
27 x 10 - 12 (250/75-12)	14	7.00
	20	10.00
23 x 5	6	5.25
	8	6.50
7.00 -15	14	9.25
7.50 - 15	12	8.25
	16	10.00
8.25 - 15	18	10.00
28x9-15 (8.15-15) (225/75-15)	14	10.00
250 - 15 (250/70-15)	18	9.50
300 -15 (315/70-15)	22	10.00
10.00 - 20	18	10.00
12.00 - 20	20	10.00
Tel: 22 723 92 90		